

## **Apéndice F. Código de conversión valor RAW a temperatura publicado por Kekoa Proudfoot.**

```
case a0: // temperature in degrees C
case c0: // temperature in degrees F
    if (raw >= 3a0 || raw < 122)
        sensor->value = 7ffff
    else if (raw < 154)
        scale = fffffefb
        offset = 00023730
    else if (raw < 186)
        scale = fffffff3e
        offset = 0001e078
    else if (raw < 1de)
        scale = ffffff70
        offset = 0001944c
    else if (raw < 208)
        scale = ffffff85
        offset = 00016da0
    else if (raw < 316)
        scale = ffffff95
        offset = 00014cd0
    else if (raw < 376)
        scale = ffffff7a
        offset = 0001a068
    else
        scale = ffffff51
        offset = 00022d08
    temp = (raw * scale + offset) / 100
    if (sensor->mode & 0e == 0a)
        // temperature in degrees C
        sensor->value = temp
    else
        // temperature in degrees F
        sensor->value = degf = (temp * 12) / 0a + 140
```